WM-FX281/FX481/FX482ST

SERVICE MANUAL

Ver 1.2 2002.02

US Model
WM-FX281/FX481/FX482ST
Canadian Model
AEP Model
WM-FX481

• The following parts are an available for service parts of this model.

PARTS LIST

Part No.	Description	Remark
3-030-062-21	LID, BATTERY CASE	
3-228-752-11	MANUAL, INSTRUCTION (ENGLISH)(US)	
3-228-752-21	MANUAL, INSTRUCTION (ENGLISH, FRENCH, SIMPLIFIED, CHINESE)(Canadian,AEP, FR)	
3-228-752-31	MANUAL, INSTRUCTION (SPANISH, PORTUGUESE, GERMAN, ITALIAN)(AEP)	
3-228-752-41	MANUAL, INSTRUCTION (DUTCH, SWEDISH, FINNISH)(AEP)	
3-228-752-62	MANUAL, INSTRUCTION (ENGLISH, RUSSIAN, HUNGARIAN)(CEV)	
3-228-752-72	MANUAL, INSTRUCTION (POLISH, CZECH, SLOVAK)(CEV)	
8-953-130-90	HEADPHONE, MDR-E805LP (FX481 : AEP, FR, CEV)	
8-953-273-83	RECEIVER, EAR MDR-G051LP (FX482ST)	
8-953-775-90	RECEIVER, EAR MDR-026LP (FX281: US / FX481:US, Canadian)	

• Abbreviation
FR : French
CEV : Polish, Czech, Greece, Turker

RADIO CASSETTE PLAYER

9-873-101-13
2002B0200-1
© 2002.02

Sony Corporation
Personal Audio Company
Published by Sony Engineering Corporation

SONY®